




COOKTOP PARTS

For Models: GY399LXUQ0, GY399LXUB0, GY399LXUT0, GY399LXUS0
(White) (Black) (Biscuit) (S.Steel)

30" Slide-In
Electric Range




Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10203741	Use & Care Guide
	W10203740	Installation Instructions
2		Cooktop
	W10170209	White
	W10170210	Black
	W10170211	Biscuit
	W10170212	S.Steel
3	12001676	Kit, Hardware
4	74008897	Element (LR)
5	74008568	Element (LF,RR)
6	74005759	Tube, Vent Upper
7	W10116760	Screw
8	74003072	Support,Element
9	74011799	Light, Indicator
10	74008919	Element (RF)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: GY399LXUQ0, GY399LXUB0, GY399LXUT0, GY399LXUS0
(White) (Black) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1	74005769	Lens
2		Panel, Control
	7720P535-60	Black
	7720P536-60	White
	7720P537-60	Biscuit
	W10182766	S.Steel
3	7101P309-60	Screw
4		Switch, Infinte
	74010824	8" (RF,LR)
	7403P238-60	6" (LF,RR)

Illus. No.	Part No.	DESCRIPTION
5	W10203701	Control
6		Panel,Control(lwr)
	W10185606	Black
	W10185607	White
	W10185609	Biscuit
7		Knob (LF,RR)
	7737P414-60	Black
	7737P415-60	White
	7737P416-60	Biscuit
8		Switch, Membrane
	7450P117-60	Black
	W10177224	White
	W10177226	Biscuit

Illus. No.	Part No.	DESCRIPTION
9		Knob (RF,LR)
	7737P417-60	Black
	7737P418-60	White
	7737P419-60	Biscuit
10	W10203695	Support, Control Panel
11	Y700502	Screw
12	74004153	Light, Indicator
13	W10187161	Overlay (S.Steel Mdl Only)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS


For Models: GY399LXUQ0, GY399LXUB0, GY399LXUT0, GY399LXUS0

(White)

(Black)

(Biscuit)

(S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Models: GY399LXUQ0, GY399LXUB0, GY399LXUT0, GY399LXUS0

(White)

(Black)

(Biscuit)


(S.Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Panel, Shield	20	74008597	Smoke Eliminator	39	74007129	Support
	74010821	Left	21	74010809	Plate, Smoke Elm.	40	74003565	Runner, Drawer (2)
	74010822	Right	22	74010885	Light Assembly	41	74004078	Roller, Drawer (2)
2	74010819	Latch Assembly	23	74004180	Bracket,Pwr Supply	42	74005231	Shaft, Roller (2)
3	74010807	Cover, Front	24	7407P103-60	Bulb, Oven	43	74005230	Nut, Lock (2)
4	74011465	Main Back	25		Trim, Side	44	74006522	Retainer, Bottom
5	W10203736	Cover, Main Wire		74010832	White (2)	45	W10116760	Screw
6	74010815	Extension, Back		74010831	Black (2)	46	74008315	Cover,Conv.Fan
7	Y700502	Screw	26	71001394	Screw	47	W10159823	Trim, Front
8	74006364	Insulator, Cord	27	74010811	Element, Bake	48	W10116760	Screw
9	74010814	Retainer, Insul.	28	74010884	Support, Oven Rear	49	W10171550	Switch, Light
10	W10177095	Shield, Warmer	29	71001394	Screw	50	74011094	Fan, Convect
11	74010823	Fan, Cooling	30	74011142	Hinge (2)	INSULATION		
12	74010812	Support,Oven Btm	31	4159193	Screw, Hinge (4)		74010987	Insulation, Wrap
13	7101P124-60	Screw	32	74010818	Switch, Hi-Limit		W10165725	Insulation, Back
14	74003040	Element, Broil	33	74005564	Bracket,Anti-Tip		74010986	Insulation,
15	74004943	Sensor, Oven	34	74010820	Extention, Shield			Oven Bottom
16	W10165722	Tube, Vent Lower	35	74003386	Support, Element			
17	74010816	Tube, Vent Upper	36	74010805	Leg, Leveling			
18	W10116760	Screw	37	74010899	Pedestal, Bottom			
19	74010817	Holder, Vent Tube	38	74010882	Pedestal, Front			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: GY399LXUQ0, GY399LXUB0, GY399LXUT0, GY399LXUS0
(White) (Black) (Biscuit) (S.Steel)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	W10165729	Trim, Door Top	14	74009693	Trim, Door Side	18	W10162384	Seal, Door
	W10165726	Black		74009695	Black, Left	19		Glass, Door
	W10177497	White		74009697	White, Left		W10170228	White
	W10168887	Biscuit		74009692	Biscuit, Left		W10170229	Black
2	W10163951	Screw, Handle (2)		74009694	Black, Right		W10170230	Biscuit
3	74011457	Baffel, Retainer		74009696	White, Right		W10170231	S.Steel
4	74001530	Screw 8AB 1/2			Biscuit, Right	(Order Items 13 & 21 When Replacing Door Glass)		
5	74003645	Glass, Inner (2)	15	74009014	Tape, Double Sided			
6	74005546	Spacer, Rubber		74009025	White	20		Handle, Door
7	74001574	Nut, Snap (4)			Black		W10118430	White
8	74011456	Lining, Door	16	74009687	Trim, Door Bottom		W10118431	Black
9	74011458	Bracket, Glass (2)		74009686	White		W10118432	Biscuit
10	74003647	Insulation, Door		74009688	Black		W10144883	S.Steel
11	Y700502	Screw			Biscuit	21	74003664	Tape, Foil
12		Bracket, Handle	17		Screw, Trim		8303810	Nameplate, Logo
	74009699	Left		74009540	White	22	74010267	Spacer, Rubber
	74009698	Right		74009539	Black			
13	74004224	Tape, White		74009541	Biscuit			
				74009268	S.Steel			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRAWER AND RACK PARTS

For Models: GY399LXUQ0, GY399LXUB0, GY399LXUT0, GY399LXUS0
(White) (Black) (Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1	74011813	Rack, Oven (2)
2	74008333	Drawer, Storage
3	74004310	Screw, Panel
4	74010896	Bracket, Drawer

Illus. No.	Part No.	DESCRIPTION
5		Panel, Drawer
	74003407	White
	74003701	Black
	74004966	Biscuit
	W10160943	S.Steel
6		Screw, Panel
	74009540	White
	74009539	Black
	74009541	Biscuit
	74009538	S.Steel

Illus. No.	Part No.	DESCRIPTION
7	74005230	Nut, Lock
8	2404F030-51	Lining, Drawer
9	74005546	Spacer, Rubber
10	74004078	Roller, Drawer (2)
11	74005231	Shaft, Roller (2)
12	7103P082-60	Nut
13	74009589	Rack, Half
14	74009587	Insert, Rack

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: GY399LXUQ0, GY399LXUB0, GY399LXUT0, GY399LXUS0

(White)

(Black)

(Biscuit)

(S.Steel)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Parts Not Illustrated and
Optional Parts (Not Included)

SPLICING WIRES--25FT.

LENGTH

242828	Wire, Black
	12 Ga. 150° c
242821	Wire, Blue
	14 Ga. 150°c
242822	Wire, Brown
	14 Ga. 150°c
242830	Wire, Brown
	14 Ga. 200°c
242823	Wire, Green
	14 Ga. 150°c
242824	Wire, Orange
	14 Ga. 150°c
242825	Wire, Red
	14 Ga. 150°c
242831	Wire, Red
	14 Ga. 200°c
242827	Wire, Yellow
	14 Ga. 150°c

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

REFINISHING MATERIAL

799832	Kit, Porcelain
	Repair (White)
242756	Touch-Up
	Self-Clean(1/2 Pt)
261582	Grease

INSULATION

261514	Insulation,
	Fiberglass (1-1/2"
	x 24" x 120")
240132	Insulation,
	Fiberglass (2-1/2"
	x 22" x 120")

PAINT, TOUCH-UP (1/2oz.)

72017	White
4392899	Biscuit
511873	White Porcelain
	(2 Oz.)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
4392901	Biscuit
285006	Superior Black
206922	Primer (White)

PAINT, BULK (1 qt.)

799344	White (Uncut)
4392900	Biscuit(Uncut)

ACCESSORY PARTS

241430	Foil, Aluminum
	Oven (18" x 25')
3191048	Cleaner, Glass

WIRING HARNESS PARTS

74010849	Harness, Sensor
W10204629	Harness, Top
74011549	U3, Harness (RT)
74011572	Coil,Harness (Lt)
5171P976-60	Harness, Main
74006811	Clip, Wire

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST